



Pole Mounting



Wall Mounting

1. Insert small diameter cable and fix it.



2. Connect small diameter cable with splitter input cable by fusion splicing or mechanical splicing.



Splitter input cable

3. Fix the 1x8 or 1x16 splitter as below



1x16 or 1x8 Splitter

4. Connect splitter ribbon fibers with output pigtails that coated loose tube as below



Splitter

5. Fix the arranged output pigtails with loose tube to tray.



6. Lead output pigtail to the other side of the tray, and insert adaptor as below



7. Pre-insert optical drop cables to outlet holes in order, then seal it by soft block.



8. Pre-installed field assembly connector of drop cable, then insert connector to optical adapter in order and tie it by cable tie



9. Close the cover, the installation is finished.

